




K100/K101 Series



User Manual



- EN User Manual
- DE Bedienungsanleitung
- JP ユーザーマニュアル
- KR 사용설명서
- FR Manuel d'utilisation
- ES Manual de Usuario
- PT Manual de Utilizador
- RU Руководство пользователя

www.pccooler.com | Q

Manufacturer: Shenzhen Fluence Technology PLC.
Address: A701, Plant 1, TianAn Cyber Innovation Park, No. 475, Huangge North Road,
Huanggekeng Community, Longcheng Street, Longgang District, Shenzhen, China.
Tel: (+86) 755 8451 1665 E-mail: support@pccooler.cn





Item 项目/Q'ty 数量	Name 名称	Used for 用途
A  x18	Screw M3 5mm	Motherboard/SSD; 主板/SSD
B  x6	Screw #6-32 6mm六角螺丝	PSU/PCIE Card; 电源/PCIE卡
C  x4	Screw #6-32 5mm圆头螺丝	3.5"HDD; 3.5"硬盘
D  x3	Screw #6-32 6.5mm	Motherboard Stud; 主板板螺丝
E  x5	Cable ties束线带	Cable management; 理线

- 5  安装机械硬盘
Install 3.5 inch HDD
- 6  安装电源
Install Power Supply Unit



- 1  取下机箱侧板
Remove the side panel
- 2  主板安装
Install the Motherboard

- 7  安装显卡
Install Graphics Card
- 8  安装显卡
Install Graphics Card



- 3  安装PCI-E延长线
Install the PCI-E Riser Cable
- 4  安装固态硬盘
Install 2.5 inch SSD

- 9  安装风扇
Mount Fans
- 10 产品分解图
Decomposition Diagram

