


DS/DC Series

01. Buckle and accessories

A


LGA 1851/1700/1200/115X



x1


B

AM4/AM5



x1

C



x1


D




240x8 360x12

INTEL: A C D
AMD: B C D

02. 240Fan water drain installation




03. 360Fan water drain installation




04. INTEL-LGA 1851/1700/1200/115X

1




LGA 115X/1200 ◁ ▷ LGA 1851 /1700

2




05. INTEL-LGA 1851/1700/1200/115X

1




2




3

LGA 115X/1200 ◁ ▷ LGA 1851/1700




06. AMD - AM5/AM4

1




2




07. AMD - AM5/AM4


1



2




3




4

B



08. 360Fan pump wiring diagram



AIO_PUMP ARGB CPU_FAN

EN For more information, please check our website at: www.pccooler.com.
DE Für weitere Informationen besuchen Sie bitte unsere Website unter: www.pccooler.com.
FR Pour plus d'informations, merci de visiter notre site internet: www.pccooler.com.
ES Para más información, por favor,visite nuestra página en: www.pccooler.com.
IT Per ulteriori informazioni, visitate il nostro sito web: www.pccooler.com.
PT Para mais informação, vista o nosso website em: www.pccooler.com.
CS Další informace najdete na našich webových stránkách: www.pccooler.com.
KO 자세한 내용은 www.pccooler.com 에서 확인하실 수 있습니다.
AR www.pccooler.com یردنی بازاره موتمنا علی
TH www.pccooler.com
SV För mer information, gå till vår hemsida på: www.pccooler.com.
PL Więcej informacji można znaleźć na naszej stronie internetowej: www.pccooler.com.
TR Daha fazla bilgi için, lütfen websitenizi ziyaret edin: www.pccooler.com.
RU Больше информации на сайте: www.pccooler.com.
UK Щоб отримати додаткову інформацію, перегляньте наш веб-сайт: www.pccooler.com.
KK Көбірек ақпарат алу үшін біздің вебсайтымызға кіріңіз: www.pccooler.com.
JA 詳細については、以下URL先の公式WEBサイトをご確認ください: www.pccooler.com.
VI Để biết thêm chi tiết, vui lòng kiểm tra tại website: www.pccooler.com.
ZH 如需更多信息, 請瀏覽網站: www.pccooler.com.
ZH 如需更多信息, 請瀏覽網站: www.pccooler.com.

"PCCOOLER", "PC COOLER", "超頻王" and other commercial identities are legitimate registered trademarks and commercial identities of the trademarks owner and its affiliates in China and other countries or regions.
Copyright © 2023 Shenzhen Fluence Technology PLC. All rights reserved.
Pictures on this package are for reference only, please refer to the actual product.

Manufacture:Shenzhen Fluence Technology PLC.
Address:LongGang TianAn Cyber Innovation Park 518116 CN
Tel:(+86) 755 8451 1665 E-mail:support@pccooler.cn

屏显功能使用说明
Instruction for Temperature Display Function

1.应用程序下载:
1.Application Download:
★ 1.1 手动下载:可访问超频三官网 (www.pccooler.cn), 在产品页面找到相应的产品, 打开详情页面在“资料下载”处下载应用程序。
1.1 Manual Download: Visit the official website of PCCooler (<http://www.pccooler.com>), find the specified model in the product categories, and select the “Download” section to download the setup executable file.
www.pccooler.cn
★ 1.2 扫码下载:扫描如下二维码下载应用程序。
1.2 Download by QR Code: Scan the QR code below using mobile device camera to download the setup executable file.

扫码下载
Scan QR Code to Download

使用教程
User Manual

2.应用程序安装:
2. Application Installation:
★ 2.1 将下载的文件解压缩, 双击应用程序安装。
2.1 Unzip the downloaded file and double click the setup executable file to start installation.

CPS_Display
★ 2.2 安装完成后, 打开应用程序即可开启屏显功能。
2.2 After the installation is completed, the temperature display function is automatically enable when the application is running.