


User Manual
Mode d'emploi



01.PACKAGE CONTENT


01.CONTENU DU PAQUET



02.INTEL&AMD


02.INTEL et AMD

AMD:AM4/AM5:E,G,H
Intel LGA:115X/1200/1700/1851:C,D,G,H




03.INTEL&AMD


03.INTEL et AMD




04.INTEL-LGA 115X/1200/1700/1851




05.INTEL-LGA 115X/1200/1700/1851



06.AMD-AM4/AM5




07.AMD-AM4/AM5




08.INTEL&AMD

08.INTEL et AMD




09.INTEL&AMD

09.INTEL et AMD



10.INTEL&AMD (FAN)

10.INTEL et AMD (VENTILATEUR)



11.INTEL&AMD (ARGB)

11.INTEL et AMD (ARGB)

